

# **IP WEB**

## **User Guide**

**V1.0**

Please read carefully before contacting your supplier.

Information is correct at time of printing, but can be subject to change without notice, whilst every effort has been made for accuracy product improvements may enhance the features or functions.

# --CONTENT--

<b>FIRST CHAPTER WEB LOGGING IN .....</b>	<b>3</b>
1.1 ACTIVE X CONTROL SETTING.....	3
1.2 WEB LOGIN.....	4
<b>THE SECOND CHAPTER DEVICE CONFIGURATION.....</b>	<b>4</b>
2.1 LIVE VIDEO.....	4
2.2 EQUIPMENT INFORMATION.....	5
2.3 STREAM CONFIGURATION.....	6
2.4 ROUTE MAPPING .....	6
2.5 DEVICE CONFIGURATION .....	7
2.5.1 Local Network.....	7
2.5.2 Device port.....	8
2.5.3 ADSL Network.....	8
2.5.4 multicast.....	9
2.5.5 camera.....	9
2.5.6 Date & time .....	10
2.5.7 OSD settings .....	10
2.5.8 Microphone setting.....	11
2.5.9 Dome PTZ.....	11
2.5.10 system service .....	11
2.5.11 system Configuration.....	12
2.6 EXTERNAL DEVICE .....	12
2.6.1 PTZ.....	12
2.6.2 PTZ Keyboard .....	13
2.6.3 cash Registers.....	13
2.7 ALARM CONFIGURATION.....	14
2.7.1 Alarm I/O Parameter Configuration.....	14
2.7.2 Disk Alarm configuration.....	15
2.7.3 I/O Alarm Linkage configuration .....	15
2.7.4 Motion Alarm configuration.....	16
2.8 LOCAL RECORD .....	17
2.8.2 Record Directory.....	19
2.9 PRIVACY MASKING SETTING.....	21
2.10 NETWORK SERVICE .....	22
2.10.1 NTP.....	22
2.10.2 PPPoE.....	23
2.10.3 DDNS .....	23
2.10.4 Update.....	24
2.11 SERVICE CENTER .....	24
2.11.1 Alarm center.....	24
2.11.2 SMTP.....	25
2.12 PRIVILEGE MANAGER.....	26
2.12.1 Authority group setting.....	26

---


2.12.2 user setting .....	26
2.13 PROTOCOL .....	27
2.13.1 Protocol information .....	27
2.13.2 Security .....	27
2.13 DEVICE RESTART .....	27
2.15 DEFAULT SETTINGS .....	27

## First chapter web logging in


### 1.1 ActiveX control setting

Before the WEB log on, we need to set IE ActiveX controls first.

Clicking the right mouse , selecting "Attribute", system pop up dialog as follows:




Select "security" ☐ "Custom level"), system pop up dialog as follows:




Put options "download unsigned Actives control" to be enabled. Or directly put the Internet safety to a minimum.

## 1.2 WEB login




After ActiveX to be set, click  icon on the desktop, open IE browser, currently this is the only support browser, input the IP address of the IP equipment which you want to land in the IE browser address bar. Press the Return Key (ENTER), and ensure be right to enter your user name and password in login dialog then you can access IP equipment. The default IP address of IP equipment is: **192.168.0.120**, the default IP equipment user name and password is: **admin**

The image shows a web login interface. At the top, there is a blue header with a camera lens image on the left and some small, illegible text on the right. Below the header, there is a light blue login form. The form contains three input fields: 'Language' with a dropdown menu showing 'English', 'User Name' with the text 'admin', and 'Password' with six dots. At the bottom of the form is a 'Login' button with a blue checkmark icon.

## The second chapter device configuration



### 2.1 Live video

After you have logged in correctly, you will be presented with the display as below: With mouse over the video window double mouse click will enter video into full screen mode. Other camera settings are available as labeled including video stream and PTZ control functions.



## 2.2 Equipment information

On left side of the main window features all the "equipment information" settings. This is the entire configuration setup for the device, such as IP information audio settings network parameters' etc. Device Information is used to show the capabilities of the device and also the master Device Name.



## 2.3 Stream configuration

Click features list on the left, select "Stream configuration", then you can configure stream video for the current IP equipment. As the following figure shows:

The screenshot displays the 'Stream Configuration' window. At the top, there's a 'Camera Id' dropdown set to '1'. Below it, a 'Stream Configuration' section is highlighted. Inside this section, the 'Stream Id' is set to '1'. The 'Name' field contains 'stream1'. The 'Video Encode Type' is set to 'H264 Main Profile', and the 'Audio Encode Type' is set to 'G711\_ULAW'. The 'Resolution' is set to '1920x1080', 'Frame Rate(fps)' is '22', and 'I Frame Interval' is '1'. The 'Bit Rate(kbps)' is set to 'CBR' with a value of '10000' and a range '(500-12000kbps)' shown. The 'Quality' is set to '7'. At the bottom, there are 'OK' and 'Reset' buttons.

Each device can be configured for different video stream; each device can be configured with up to three different video streams. This let you set a high quality recording stream and perhaps a low level stream for remote monitoring.

Resolution: According to the actual resolution to actual resolution of IP equipment divided :into :1920x1080/1280x960/1280x720/1600x1200/D1/CIF/QCIF etc.

Frame rate: PAL can be up to 25fps and NTSC up to 30fps

I Frame interval: time interval between I frames divided into 1/2/3/ seconds three types, for higher bit rate of the screen, should shorten frame spacing. The smaller frame interval, it is good to increase position accuracy of video return, and advantageous to the network video when the recovery of shaking. If frame interval become small, the video streaming will become big, unless understand the reason the default value 2 should be used.


Bit Rate: Either CBR or VBR. CBR is constant bit rate, where the daa streamed will be at a constant value.; VBR that is variable bit rate, where compression data can change relative to the complexity of the compression of the scene, relative to the quality setting below.

Quality: Value 1-9 choose within quality. The higher the quality values the clearer images will.

Hint: setting a high quality value and a small VBR bitrate may not provide the ideal settings. Unless required a quality setting of 7 is acceptable.

## 2.4 Route Mapping

Through the routing mapping IP equipment can be realized to WAN network requests through a router.



**Router Mapping**

Router Mapping

☐ Enable Router Mapping

Router Address:

Control Mapping Port:

☒ OK ☐ Reset


The router address: fill the router WAN address, support filling in domain name address, such as test.gicp.net.

Control mapping port should remain consistent with control ports of "device configuration"- "equipment port" Default should be 3001

This function detailed please refer to the document "set instructions of IP equipment WAN nets visit".

## 2.5 Device configuration

### 2.5.1 Local Network



**Local Network**

IP Protocol: IPv4

IP Address

☐ Device obtain an IP address automatically

☒ Device user the following IP address

IP Address:

Subnet Mask:

Default Gateway:

DHCP IP

DHCP IP:

DNS

Preferred DNS Server:

Alternate DNS Server:

☒ OK ☐ Reset



It Can set the network IP camera address, subnet mask, gateway, DNS and other network parameters, If it is used in local area network you should be careful that not to set up the internal LAN IP address and computer IP address to cause a conflict. If a HDCP is set then the current IP is display here.

If you want to use the IPv6 protocol equipment, first in the IP protocol IPv6 protocol options to choose and modify the network parameters, click on the "Apply" button.

### 2.5.2 Device port

The screenshot shows the 'Device Port' configuration window. It has a title bar with a blue icon and the text 'Device Port'. Below the title bar is a blue header with a green arrow icon and the text 'Device Port'. The main area contains three rows, each with a label and a text input field: 'Control Port' with '30001', 'Http Port' with '80', and 'RTSP Port' with '554'. At the bottom are two buttons: 'OK' with a blue checkmark icon and 'Reset' with a blue circular arrow icon.

Control port: The default is 30001, including the parameters of reading and writing, PTZ control are both through this port to control;

TCP audio and video port: The default is 30002, for the TCP protocol under the audio and video transmission which needs of the port number.

Http Port: Default is 80, for Web access to use the port number. If you change it to another port number, you need add “: port number” in the address bar at the end. For example, the equipment which IP is 192.168.10.96 and the Http port is changed to “8080”, you could enter the http://192.168.10.96:8080 in the IE browser's address bar to access the network device through the Web.


RTSP Port is use for streaming video. Only requirement to change this is if you are using multiple devices on one IP which would require all ports to be modified

### 2.5.3 ADSL Network

The screenshot shows the 'ADSL Network' configuration window. It has a title bar with a blue icon and the text 'ADSL Network'. Below the title bar is a blue header with a green arrow icon and the text 'IP Protocol'. The main area contains two sections: 'IP Protocol' with a dropdown menu showing 'IPv4', and 'IP Address' with an empty text input field.

When the user set "Network Service" ☐ "PPPoE parameters", after the success of dial-up equipment, Equipment's WAN network IP address will appear in the page.

## 2.5.4 multicast



**Multicast**

▶ Multicast

Camera: 1


IP Addr:

Port:

Confirm Reset

This function can make a single flow provide more network receivers.

## 2.5.5 camera



**Camera**

Camera: 1

▶ Channel

Channel Name: Set

▶ Video System \ Source Resolution

Video System: 50Hz

Source Resolution: 1920x1080 Set

Camera name: Name of the camera settings will be displayed in real-time monitoring

Video formats whether to modify the device's PAL/NTSC system, this function is dependent on the model if supported.

Source resolution: set video source resolution for the 4:3 or 16:9.usually D1 resolution for the 4:3,704×384 resolution for 16:9. Also allows lower video resolution for 2Mega Pixel solutions.

## 2.5.6 Date & time

**Date&Time**

☒ Date&Time

Device Time: 1999-12-1 4:54:12

Current PC Time: 2012-2-28 13:46:30

Set Manually: 2009-10-10 10:10:10

Select the method to use for setting the time: one is to set the time according to the clock on your computer; another is to manually enter the time and date.

## 2.5.7 OSD settings

**OSD**

Camera: 1

☒ OSD

☒ Device Name

Row: 0 Column: 0

☒ Channel ID

Row: 1 Column: 0

☒ Channel Name

Row: 2 Column: 0

☒ Time

Row: 3 Column: 1

Time Format: YYYY-MM-DD hh:mm:ss ww

☒ Custom


Row: 4 Column: 0

Custom OSD:

Respectively for different resolutions of network device to set OSD parameters, a tick indicates this information is displayed as overlay on encoded video stream including: device name, channel number,

channel name, time and custom OSD.

### 2.5.8 Microphone setting



The interface for Microphone settings is shown within a tabbed window. The 'Microphone' tab is selected. Below the tab, there is a 'Camera' dropdown menu set to '1'. A blue bar with a green play icon and the text 'Microphone' is present. Below this bar, there is a checkbox labeled 'Enable Microphone' which is checked. At the bottom, there is a 'Microphone Type' dropdown menu set to 'Internal'.


Microphone Type:

Internal: built-in microphone. (if fitted)

External: Where supported will select the Audio Input as audio source for Line in:

Audio is encoded inside the video stream, audio format is set under the Streaming Settings.

### 2.5.9 Dome PTZ



The interface for Dome PTZ settings is shown within a tabbed window. The 'Dome PTZ' tab is selected. Below the tab, there is a blue bar with a green play icon and the text 'Dome PTZ'. Below this bar, there is a 'PTZ Address' text input field.


IP high-speed dome can set PTZ address.

### 2.5.10 system service



The interface for System Service settings is shown within a tabbed window. The 'System Service' tab is selected. Below the tab, there is a blue bar with a green play icon and the text 'System Service'. Below this bar, there are two checkboxes: 'FTP Server' and 'Telnet Server', both of which are checked. At the bottom, there is a note in blue text: 'Note: The IP Camera provides advanced functions that allows professional users to debug by themselves. We strongly recommend that you do not use this function unless you fully understand the consequences.'

### 2.5.11 system Configuration




The screenshot shows the 'System Configuration' page with a sub-tab for 'Language Configuration'. Below the sub-tab, there is a 'Language:' label followed by a dropdown menu currently set to 'English'.

Change the language for week OSD and alarm E-mail of the IP device.

## 2.6 External Device

IP equipment can connect external equipment such as external PTZ, PTZ keyboard and currency counting.

### 2.6.1 PTZ




The screenshot shows the 'PTZ' configuration page. It includes the following fields and options:

- Camera: 1 (dropdown)
- ☒ Enable PTZ
- PTZ Protocol: Pelco-D (dropdown)
- PTZ Address: 1 (text input)
- Serial Port: COM1 (dropdown)
- Baud Rate: 4800 (dropdown) bps
- Data Bits: 8 (dropdown) bit
- Stop Bits: 1 (dropdown) bit
- Parity Verification: None (dropdown)

When connect external PTZ control device via the serial, used for older style pan/tilt devices, you can configured PTZ agreement address, bit rate, data bit.

## 2.6.2 PTZ Keyboard



PTZ Keyboard

PTZ Keyboard

☒ Enable

Interface Type: RS485

Serial Port: COM1

Baud Rate: 4800 bps


Data Bits: 8 bit

Stop Bits: 1 bit

Parity Verification: None

When connect PTZ keyboard, you can configure interface type, serial ports, bit rate, data bit.

## 2.6.3 cash Registers



Cash Registers

Cash Registers

☐ Enable

Row: 0 Column: 0

Channel: ☐ 1

Interface Type: RS485

Serial Port: COM1

Baud Rate: 4800 bps

Data Bits: 8 bit

Stop Bits: 1 bit

Parity Verification: None

When connect external cash, can add the number that currency counting counts to the video though OSD.

**Note:** this function needs especial external equipment to support this function.

## 2.7 Alarm configuration

Alarm configuration, including alarm I/O port configuration, Disk warning, I/O alarm linkage, and motion detection alarm.

### 2.7.1 Alarm I/O Parameter Configuration

The screenshot shows a web-based configuration interface for Alarm I/O. It has a tab labeled 'Alarm I/O'. Under the 'Alarm In' section, there are three fields: 'Alarm In:' with a dropdown menu set to '1', 'Name:' with a text box containing 'one', and 'Valid Voltage Level:' with a dropdown menu set to 'High'. Under the 'Alarm Out' section, there are five fields: 'Alarm Out:' with a dropdown menu set to '1', 'Name:' with a text box containing 'one', 'Valid Signal:' with a dropdown menu set to 'Close', 'Alarm Out Mode:' with a dropdown menu set to 'Switch Mode', and 'Frequency:' with a text box containing '0' and a unit 'Hz'. At the bottom, there is an 'Alarm Time:' field with a text box containing '125634' and a unit 'ms (0:Alarm forever)'.


Alarm input: Select the alarm input configuration ID, the alarm can be chose the effective level. Effective level include: high and low two options. When you select high effective input port when access to high level alarm that is triggered by alarm signals, When you select low effective input port when the alarm signal that is triggered off high alert.

Alarm output: Select the alarm output configuration ID, the effective signal, alarm mode and alarm output timing parameters.

Effectively including closed and disconnects signals two options: Alarm output model, including switch-mode and square-wave mode, When the choice of square-wave mode, can fill in the frequency of square-wave output, unit is Hertz.

**Note: the unit of Alarm Time is millisecond.**

## 2.7.2 Disk Alarm configuration



**Disk Alarm**

**Disk Full Alarm Configure**

☒ Disk Full Alarm

Max Disk Space:  %


**Disk Error Alarm Configure**

☒ Disk Error Alarm

Disk Alert configuration including: disk error alarm and disk full alarm. Disk alarm will be recorded in the alarm log.

## 2.7.3 I/O Alarm Linkage configuration

Note: Before the opening of the record, we must first configure the "Local Record" ☐ "Record Policy" parameter.



**I/O Alarm Linkage**

Alarm I/O:

**Enable I/O Alarm**

☒ Enable Schedule

**Output**

Output Channel: ☒ 1

**PTZ**

Camera ID:

Type:

Name:

Set Clear

Options need to configure the alarm I/O of the ID number, can be configured in the Alarm I/O trigger the alarm when the linkage. Including whether the alarm output and whether or not such as the opening of PTZ.

First of all, check "Enable IO alarm ", and then click on the "Time Setting" set the I/O warning time of deployment:



Schedule Time Setting						
Week	Period 1		Period 2		Period 3	
	Begin Time	End Time	Begin Time	End Time	Begin Time	End Time
Monday	0:00	23:30	0:00	0:00	0:00	0:00
Tuesday	0:00	23:30	0:00	0:00	0:00	0:00
Wednesday	0:00	23:30	0:00	0:00	0:00	0:00
Thursday	0:00	24:00	0:00	0:00	0:00	0:00
Friday	0:00	24:00	0:00	0:00	0:00	0:00
Saturday	0:00	24:00	0:00	0:00	0:00	0:00
Sunday	0:00	24:00	0:00	0:00	0:00	0:00

## 2.7.4 Motion Alarm configuration

Note: Before the opening of the record, we must first configure the "Local Record" □ "Record Policy" parameter.

**Motion Alarm**

---

Camera ID:

**Motion Parameter**

☒ Enable

**Output**

Output Channel: ☒   
                                   1

**PTZ**

Camera ID:

Type:

Name:

Options the camera that need to configure ID number, can be configured to detect movement of the camera to trigger the alarm when the linkage. Including whether the alarm output and whether or not such as the opening of PTZ.

First of all, select "Enable Motion Detection", then click on the "Time Setting" set the camera to detect movement of the deployment time.

Schedule Time Setting						
Week	Period 1		Period 2		Period 3	
	Begin Time	End Time	Begin Time	End Time	Begin Time	End Time
Monday	0:00	23:30	0:00	0:00	0:00	0:00
Tuesday	0:00	24:00	0:00	0:00	0:00	0:00
Wednesday	0:00	24:00	0:00	0:00	0:00	0:00
Thursday	0:00	24:00	0:00	0:00	0:00	0:00
Friday	0:00	24:00	0:00	0:00	0:00	0:00
Saturday	0:00	24:00	0:00	0:00	0:00	0:00
Sunday	0:00	24:00	0:00	0:00	0:00	0:00

Require the deployment of the week, and set the beginning and ending days of deployment time, click the "Add" button, click "OK" button.

Click on "Detection of regional Configuration":

Area Motion: Press and hold the left mouse button on the video in order to facilitate the sliding region configured to detect regions, when the need to remove the detection region can click the right mouse button. The most mobile region can not detect more than eight.

Area mask: Hold down the left mouse button within the region to add a mask area, when the need to remove the mask area, you can click the right mouse button.

Note: The maximum number of areas is 8.

## 2.8 local Record

Local recording settings is the SD memory card, NAS and FTP video parameters. Once configured, the device can record video directly to a SD card, NAS and FTP.

### 2.8.1Record policy

**Record Policy**

---

Camera ID:

---

**Schedule Record**

☒ Enable

☒ 24\*7H Record    ☐ Schedule Record

---

**Alarm Record**

☒ Enable    ☐ Locked Files

Pre Record:  Sec (0-30Sec)

Post Record:  Sec

I/O Alarm ,Alarm In: ☒   
 1

Motion Alarm,Channel: ☒   
 1

---

**Record Quality**

Stream:

Resolution:

Frame Rate(fps):

I Frame Interval:

Bit Rate Type:

Bit Rate(kbps):

Quality:

---

**Record Rule**

Disk Group:

☒ Record Audio

Storage Rule:

Number of Days:

Need to set up the camera to choose ID, you can set the camera to record the quality of SD cards, including: resolution, frame rate, bit-stream parameters.

Schedule Record: Including 7X24-hour record and schedule record. When you select from time to time recording, click the "set-up time",

Week	Period 1		Period 2		Period 3	
	Begin Time	End Time	Begin Time	End Time	Begin Time	End Time
Monday	0:00	0:00	0:00	0:00	0:00	0:00
Tuesday	0:00	0:00	0:00	0:00	0:00	0:00
Wednesday	0:00	0:00	0:00	0:00	0:00	0:00
Thursday	0:00	0:00	0:00	0:00	0:00	0:00
Friday	0:00	0:00	0:00	0:00	0:00	0:00
Saturday	0:00	0:00	0:00	0:00	0:00	0:00
Sunday	0:00	0:00	0:00	0:00	0:00	0:00

OK Close

Select the week to record, and set recording beginning and end of the day time, click the "Add" button, click the "OK" button.

Alarm record: fill in the Length of pre-recorded and Length recorded continued, Length of pre-recorded up to 30 seconds max.


Note: Document recording the total length of time=Length of pre-recorded+ Event time length+ Length recorded continued, For example, Set the length of pre-recorded for 10 seconds, Length recorded continued for 10 seconds, Trigger motion detection for the duration of 5 seconds, While recording the total length =10+5+10=25 seconds.

Days to keep video: Retain the largest number of days for 9999 days.

Stream: Recording selected video stream ID.

### 2.8.2 Record Directory

Three default directories include SD card, NAS and FTP when setting the video equipment directory.



**Record Directory**

**Record Directory Information**

Disk Name: SD1

Disk Type: SD Card

Group ID: 1

Enable Flag: Yes


Usable Space: 0 M

Status: N/A

File System: unknow

Modify

1. **SD card:** SD Card: Click on the SD card entry, click on the button "modify", you can format the SD card, the following figure:



**Record Path Modify**

☒ Enable

Disk Name: SD1

Group ID: 1

Usable Space: 0 M

File System: SDVideo

Format

OK Close

Disk name: can be set to directory name.

Disk group: the default into 1-8 group.

Available space: the directory can be equipped with video available space 0 for not restriction of size.

File system: divided into Video and ext.

2, NAS: Click on the NAS entry, click on the button "modify", and the following figure:

Record Path Modify	
<input checked="" type="checkbox"/>	Enable
IP:	192.168.0.177
Path:	/nas2
Accounts:	administrator
Password:	.....
Confirm Password:	.....
Group ID:	1
File System:	cifs
<input checked="" type="checkbox"/>	Use All Space
Free Space:	0 Megabyte(s)
<input type="button" value="OK"/> <input type="button" value="Close"/>	

Set the correct IP address of the NAS, path, username and password, Click enabled, you can record video directly to a device on the NAS.

3. FTP: Click on the FTP entries, and click "modify" button, pop-up below

Record Path Modify	
<input type="checkbox"/>	Enable
IP:	ip
Port:	port
Accounts:	user
Password:	
Confirm Password:	
Group ID:	1
File System:	
Free Space:	128 Megabyte(s)
<input type="button" value="OK"/> <input type="button" value="Close"/>	

Set the right FTP IP address, port, account number and password, click the "opening" button, equipment video recording can directly record to the FTP. Normally ftp port is 21

## 2.9 Privacy Masking setting

Though this function we can set video covered area, the biggest support covered area is no more

than 8% total image space.

Privacy Masking


Channel: 1

Privacy Masking setting

☒ Enable Privacy Masking

Note: max privacy masking size: 8%

511  
1998-12-01 09:00:20 Wed  
端阳科技



## 2.10 Network Service

### 2.10.1 NTP

NTP

IP Protocol

IP Protocol: IPv4

NTP Service

☒ Enable NTP

NTP IP: 192.168.0.177

NTP Port: 123

NTP: Network Time Protocol. Host can automatically adjust the clock of the computer and connect sync. Click "Apply" button and then automatically adjust the time.

### 2.10.2 PPPoE

PPPoE

Enable PPPoE

User Name:

Password:

PPPoE: Network Camera support agreement based on the PPPoE WAN access. Through the client software is set up correctly PPPoE username and password, after every time you start Network Camera, PPPoE mode automatically establish a network connection, after the success of the network camera to obtain the dynamic WAN IP address.

Description: Make sure that ADSL Modem has been opened. PPPoE parameters set for the first time, the need to restart the equipment in order to establish a connection.

### 2.10.3 DDNS

DDNS

Enable DDNS

Provider: 3322

Domain Name:

Accounts:

Password:


DDNS: Dynamic domain Name service: It is better to register a domain for avoiding input IP address, as IP address is difficult to remember. It is necessary to get a PC with stable IP address in Internet, and domain name service software need to be run on the PC.(The PC will be DDNS)

After connection to network through PPPoE successfully, it is available to get IP address of extensive area network, and send name and IP address to DDNS. When client-side software visits network camera, need to find network camera name and corresponding IP address, then send the address to client-side software; finally client-side software can build network connection with network camera to get video images.

The DDNS supports the 3322 and DynDns domain name, future systems may offer additional options.



## 2.10.4 Update




The screenshot shows a web interface for configuring updates. It has a tab labeled 'Update' with a blue icon. Below the tab, there are two main sections: 'IP Protocol' and 'Update'. The 'IP Protocol' section contains a dropdown menu set to 'IPv4'. The 'Update' section contains three input fields: 'Update Server IP' with the value '192.168.0.195', 'Update Server Port' with the value '10061', and 'Update Period' with the value '1' and a unit selector set to 'Minute'.

You can be set to upgrade the server IP address and port number as well as parameters such as the upgrade cycle.

Upgrade cycle: unit is minutes; the upgrade process for each time interval to upgrade the server asked whether there is a need to upgrade the new version. Specific steps to upgrade please refer to "Chapter III."

## 2.11 Service Center


### 2.11.1 Alarm center



This screenshot is identical to the one above, showing the 'Update' configuration interface. It features a 'Update' tab, an 'IP Protocol' dropdown set to 'IPv4', and an 'Update' section with fields for 'Update Server IP' (192.168.0.195), 'Update Server Port' (10061), and 'Update Period' (1 Minute).

Alarm center: when alarm triggered ,the alarm event is sent to the alarm center as per the IP address.

## 2.11.2 SMTP



The image shows a web-based configuration interface for SMTP settings. At the top, there is a tab labeled 'SMTP' with a blue icon. Below the tab, there is a blue header bar with a green play button icon and the text 'SMTP'. The main configuration area is white and contains several fields. At the top, there is a checkbox labeled 'Enable SMTP'. Below this, there are five text input fields: 'SMTP Server Address:', 'SMTP Server Port:' (with the value '25' entered), 'User Name:', 'Password:', and 'Sender E-mail Address:'. Below these are five more text input fields for recipients, labeled 'Recipient\_E-mail\_Address1:', 'Recipient\_E-mail\_Address2:', 'Recipient\_E-mail\_Address3:', 'Recipient\_E-mail\_Address4:', and 'Recipient\_E-mail\_Address5:'. At the bottom, there is a dropdown menu labeled 'Attachment Image Quality:' with 'High' selected. The interface is separated into sections by horizontal dashed lines.

SMTP

SMTP

☐ Enable SMTP

SMTP Server Address:

SMTP Server Port:

User Name:

Password:

Sender E-mail Address:

Recipient\_E-mail\_Address1:

Recipient\_E-mail\_Address2:

Recipient\_E-mail\_Address3:

Recipient\_E-mail\_Address4:

Recipient\_E-mail\_Address5:

Attachment Image Quality:

After SMTP is enabled, when triggered by motion detection, alarm and I / O alarm will be automatically sent JPG pictures and alarm information to the recipient's mailbox.

## 2.12 Privilege Manager

### 2.12.1 Authority group setting

**Group**

Group: **Administrators**

Privilege:

Privilege Manage <input checked="" type="checkbox"/>	Live Video <input checked="" type="checkbox"/>	Network Configure <input checked="" type="checkbox"/>
RS485 Configure <input checked="" type="checkbox"/>	Update Configure <input checked="" type="checkbox"/>	NTP Configure <input checked="" type="checkbox"/>
PPPoE Configure <input checked="" type="checkbox"/>	DDNS Configure <input checked="" type="checkbox"/>	Alarm Configure <input checked="" type="checkbox"/>
Alarm Control <input checked="" type="checkbox"/>	Camera Configure <input checked="" type="checkbox"/>	Local Record <input checked="" type="checkbox"/>
File Operate <input checked="" type="checkbox"/>	Device Restart <input checked="" type="checkbox"/>	Disk Configure <input checked="" type="checkbox"/>
Modify Device Parameter <input checked="" type="checkbox"/>	Audio Configure <input checked="" type="checkbox"/>	Disk Format <input checked="" type="checkbox"/>
Record Policy <input checked="" type="checkbox"/>	Register Configure <input checked="" type="checkbox"/>	OSD Configure <input checked="" type="checkbox"/>
Device Port <input checked="" type="checkbox"/>	Router Mapping <input checked="" type="checkbox"/>	FTP Configure <input checked="" type="checkbox"/>
SMTP Configure <input checked="" type="checkbox"/>	Default Settings <input checked="" type="checkbox"/>	Stream Configure <input checked="" type="checkbox"/>
Cash Register <input checked="" type="checkbox"/>	Privacy Masking <input checked="" type="checkbox"/>	

☐ Select All

You can add, modify, or delete access group, but the default permissions group administrators can not to be deleted.

### 2.12.2 user setting

**User**

User: **admin**

Privilege Group: **Administrators**

User Status: **Normal**


Multi Login: **Yes**

You can add, modify, delete a user, but the default user admin can to be deleted. The default user can unlock the customers which input wrong password for many times.

Support more login: when the user choice "yes" in Multi login, the user can land and user the equipment on different PC at the same time.

## 2.13 protocol


### 2.13.1 Protocol information



The image shows a web interface for 'Protocol Info'. It has a tab labeled 'Protocol Info' and a sub-tab labeled 'Protocol'. Below the sub-tab, there are three fields: 'Protocol Name' with a dropdown menu showing 'onvif', 'Protocol Version' with a dropdown menu showing 'v1.01, v1.02', and 'Protocol Software Version' with a text box containing 'v1.01&1.02build001027'.

Can see the current equipment agreement name and version number.

### 2.13.2 Security




The image shows a web interface for 'Security'. It has a tab labeled 'Security' and a sub-tab labeled 'Security'. Below the sub-tab, there is a checkbox labeled 'User Verification' which is checked.

When the equipment is Onvif protocol connect, you can choose whether security checks or not.

## 2.13 Device Restart

IP CAMERA to use remote control equipment, to resume operation.



The image shows a web interface for 'Device Restart'. It has a tab labeled 'Device Restart' and a sub-tab labeled 'Device Restart'. Below the sub-tab, there is a button labeled 'Restart' with a blue square icon containing a white star.

## 2.15 Default settings

The parameter of the IP equipment will restored to the factory value.

